

Attachment of Lift-Up Trundle

Parts:

1	Trundle Deck	1	Trundle Face (2 if you ordered an extra)
3	Bolts	2	Modesty Panels and screws

Assembly Instructions:

Place the modesty panels, with the finished side facing out, on the inside of the bed post under the bed. Screw them in with screws provided. Make sure you tighten the screws so that the screw heads are recessed. (You do not want them sticking out to scratch or tear anything.) The modesty panels not only hide the trundle, but also act as a guide to help the trundle slide in and out.

Align the ledger on the trundle face underneath the deck.

**DO NOT PLACE THE FACE ON TOP OF THE DECK,
IT WILL NOT CLOSE PROPERLY.**

Using the 3 bolts, place them in the holes of the ledger underneath the trundle face and into the deck. Then screw them into the t-nuts that are in the deck. Make sure all three bolts are tight. **DO NOT PLACE BOLTS THROUGH THE TOP.**