

Metal Canopy Assembly Instructions

Included:

4 Extension Posts	1 Metal Canopy Kit
4 Metal Inserts	1 Allen Wrench

1. Use the enclosed allen wrench to screw one of each of the four inserts in the hardware bag into the tops of all four bed posts. Tighten until the top of the insert is just below the level of the wood.
2. Screw the extension posts into the inserts. Start slowly to make sure each post is straight and tighten until the extension meets the post. In order to avoid pushing the insert too far into the wood, don't push down on the extension as you screw it in.
3. Build the metal canopy according to the instructions in that kit. Raise the canopy and rest it on top of the four extension posts. Line up the holes of the canopy to the holes on top of the extension posts. Insert the dowels on the finial through the holes in the canopy and into the top of the extension post. Push down until the finials touch the metal cross beams.