

Mirror Mounting Instructions

Included:

- 2 Wooden Mirror Supports
 - 8 Screws
1. The wooden mirror supports are marked at the top with an L for Left and R for Right. Line up the supports with the pilot holes on the back of the mirror so that the L & R are toward the top of the mirror. They go on the left and right as you face the back of the mirror. Attach with four screws.
 2. Mount the mirror on top of the dresser aligning the notch in the support with the dresser top. We recommend you pre-drill holes (using a 1/8" bit) in the dresser top before using screws to attach the supports. With someone holding mirror in place, attach and tighten the bottom four screws.