

Wooden Tester/ Straight Canopy Assembly Instructions

Included:

4 Extension Posts 1 Wooden Tester Set (2 Long and 2 Short Wooden Beams)

1. Screw the extension posts into the inserts on the tops of the Headboard and Footboard posts. Start slowly to make sure each post is straight and tighten until the extension meets the post. In order to avoid pushing the insert too far into the wood, don't push down on the extension as you screw it in.
2. Build the wooden canopy by lining up 1 Short and 1 Long Tester on top of one of the extension posts. Screw the metal bolt of the finial through the holes in the canopy and into the top of the extension post. Continue until the finial touches the wooden beams. Repeat for the other three posts