

RELICS FURNITURE & FRAME CO.

2123 C Broadway Street N.E. Mpls, MN 55413
tele 612.371.0861 fax 612.371.4541
www.relicsfurniture.com

Bed Assembly Instructions:

1. If they are still present, remove square or rectangle pieces from the bottom of each bed post. These pads are for shipping protection only. If nails or screws remain in the bottom of the posts after you remove the pads, please remove them. If not removed, these items could scratch floor surfaces.
2. Insert prongs of side rail brackets into the post mounting brackets. If the prongs do not insert into fully into the slots, it may be necessary to loosen the top 3 screws on each bed post mounting bracket. Then, push down on side rail until the prongs drop all the way down to a seated position, resting on the post brackets. A rubber mallet is helpful for this procedure. If a mallet is not available, tap down on the side rail with a hammer, first placing a block of wood on the rail to protect the rail from damage.
3. If you loosened the top 3 screws, now is the time to Re-tighten them until rail & post have a snug fit. Lay included slats or Slat Roll in-between the side rails then use enclosed screws to attach slats or Slat Roll to side rails. This step is not mandatory, but it helps to create a sturdy bed. The bed is now assembled.
4. Do not move bed around the room unless it is fully disassembled. If bed is moved around room while assembled, this may loosen bracket joints & cause the bed to become unstable & possibly do damage to the bed mounting hardware.