

Relics Furniture

Twin over Full Bunk Bed Assembly Instructions

1. Place barrel nut (16 included) inside holes of side rails with cross or slotted side of barrel facing the interior face of the side rail. Make sure the opening of the nut is directed at the drilled opening on the end of the side rail. This nut will be receiving a bolt through from the bed post.
2. Insert the long bolts (16 included) through holes on headboards (Full Sections), & lower holes on footboards (Twin sections), into the nuts in the side rails. Tighten with the included hex wrench. The footboards also have one side with two holes higher up on the post. These holes are for the fixed safety rail, which gets located at the rear side of the bed. Make sure that when you are installing the side rails to these sections, the footboards mirror each other. The rails will connect one headboard to the other, and one footboard to the other. One of the rails has a safety rail attached to it. This is what we call our removable safety rail, & gets located at the front side of the bed. The removable safety rail is centered on the side rail so the ladder can be installed on either side of it. This safety rail & side rail combination are intended to be used with the footboards, as the footboards will be the higher section of the bunk.
3. Insert 4 of the short bolts into the higher holes of the footboards. Hold the fixed safety rail up to the holes & with the hex wrench, screw the bolts into the nuts that have been factory inserted to the ends of this safety rail.
4. Once the side rails & safety rail have been installed, insert 4 of the 3/8" x 2" bed pins into the holes in the top of the headboard posts. Then, install the 2 beams across the width of the Headboards. These beams carry the weight of the twin sections/ footboards. Once these beams are in place, place the remaining 4 3/8" x 2" bed pins into the holes of the beams. Then, with 2 or more people, raise the assembled footboard sections above the assembled headboard section. Lower the footboard section on to the pins of the beams that sit on the headboard sections. Once the Footboards are securely on top of the Headboards, check all side rail bolts & safety rail bolts to make sure they are all fully tightened.
5. This bed comes with 2 modesty panels, 1 per headboard section. They fit beneath the panels on the headboard sections & are installed by inserting, & tightening 4 short bolts per section, through the post & into the modesty panel, similar to the process of installing the fixed safety rail.
6. The incline ladder has two brackets, enclosed in hardware pouch. To install brackets, lay the ladder against the top rail of the bunk bed, & make sure the feet of the ladder are resting flat on the floor. Place the brackets between the ladder & the side rail. Mark the ladder where the brackets should be placed. Use the 3/4" silver screws to attach the brackets to the ladder. Attach the felt pads to the brackets to prevent them from scratching the side rail of the bed. After brackets are attached to the ladder, they should also be attached to the side rail using the same size screws.

Parts List :

(16) Long (100MM) bolts (16) Barrel bolts (12) Short (70 MM) bolts (2) Ladder brackets w/ (8) 3/4 " screws (10) Felt Pads
(1) Hex wrench (8) 3/8" x 2" steel pins for joining top & bottom bunks

Please call Relics Furniture at 877 477 8585 for any assembly or product questions. We will gladly guide you through this process. You can also email us at getrelics@yahoo.com.